

Miller 9099 Relief Step

Description

The Miller 9099 Relief Step is designed to relieve suspension trauma after a fall arrest. OSHA states that suspension trauma can occur within minutes after a fall, while waiting for rescue. The average fall rescue time is 15 minutes. The Relief Step provides support and helps blood circulation until rescue. Small and lightweight, the Relief Step attaches to any brand/style full-body harness.

Materials

Webbing:.....Polyester
 Buckles:.....Zinc plated steel
 Sleeve:.....PVC heat shrinkable tubing
 Thread:.....Polyester
 Button Snap:.....Steel
 Label:.....Tyvek®



Technical

Weight:.....0.15 lbs (0.68 kg)
 Max Working Load:.....400 lbs (181.44 kg)
 Max. Length:.....43" (1.09 m)

INSTALLATION INSTRUCTIONS



1. Mount to upper rear web strap by "choking" through loop (Be sure loop is past metal adjustments.)



2. Attach "pull tab" button loop to the front leg strap above buckle.

ACTIVATION STEPS



STEP 1: Unsnap and pull orange tab to deploy



STEP 2: Insert opposite foot into loop



STEP 3: Adjust length and step up to relieve pressure



Use two Relief Steps for optimum support

MILLER®

by Honeywell

Toll Free 800.873.5242 (press 4) • hsptechsupport@honeywell.com • www.millerfallprotection.com

⚠ WARNING! THIS DOCUMENT PROVIDES AN OVERVIEW OF FALL PROTECTION PRODUCTS AVAILABLE FROM HONEYWELL AND CARE HAS BEEN TAKEN TO ASSURE THE ACCURACY OF THE DATA. IT DOES NOT PROVIDE IMPORTANT PRODUCT WARNINGS AND INSTRUCTIONS. HONEYWELL RECOMMENDS ALL USERS OF FALL PROTECTION EQUIPMENT UNDERGO THOROUGH TRAINING, AND THAT ALL WARNINGS AND INSTRUCTIONS PROVIDED WITH THE PRODUCTS BE THOROUGHLY READ AND UNDERSTOOD PRIOR TO EACH USE. FAILURE TO READ AND FOLLOW ALL PRODUCT WARNINGS AND INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.